

Installation instructions

STOPPA

Installation steps



1. Select suitable diameter

Select the size of the air-sealing plug to match the diameter of the conduit.



2. Pre-form the penetration

Punch through STOPPA using a conical object (nail or cartridge nozzle). Create a hole that is about 60% of the cable diameter.



3. Feed the cable through

Support STOPPA at the penetration point with your hand and pull the cable through the prepared hole.



4. Create an airtight bond with the conduit

Push the plug firmly into the conduit as far as it will go.



5. You're finished!

No further sealing is required.

The flexible thermoplastic elastomer creates an airtight seal between the cable and conduit.



6. Note regarding conduit grommets

Conduits can be quickly and reliably integrated into the airtightness/windtightness layer using the ROFLEX 15-30 mm conduit grommets.

The applications and conditions described here are based on current research findings and practical experience. We reserve the right to change the recommended application designs and installation methods and to develop and thus change the properties and quality of individual products. We would be glad to inform you about the current state of engineering knowledge at the time that your installation is carried out.

The planning documentation that is available from pro clima provides further information about installation methods and design details. If you have questions, please contact pro clima Technical Support in Germany at +49 6202 278245.

MOLL**bauökologische Produkte GmbH**

Rheintalstraße 35 - 43

68723 Schwetzingen

Germany

Phone: +49 6202 2782 0

eMail: info@proclima.com